



Company Name	BONSA JACK LLC	Calibration Date	2-14-20
Address	17940 BA. FOUR TERRACE	Next Calibration Due Date	T&C
City/State/Zip	FORT MYERS, FL 33913	Service Report #	1612W

THE WEIGHING SYSTEM LISTED BELOW HAS BEEN CALIBRATED USING TEST STANDARDS TRACEABLE TO THE NATIONAL INSTITUTE OF STANDARDS AND TECHNOLOGY (NIST)

EQUIPMENT INFORMATION

Scale Type	BENCH	Manufacturer:	OHAUS	Max Capacity:	6000 G
Customer ID#	786262-3135	Model:	V71P6T	Min Division:	2 G
Location		Serial #:	8339350377	Units / Class:	III

TEST RESULTS

AS FOUND:

Test Load	Scale Indication	Error
0	0	C
100	100	C
1000	1000	C
3000	3000	C
6000	6000	0

AS LEFT:

Test Load	Scale Indication	Error
0	0	C
100	100	C
1000	1000	C
3000	3000	C
6000	6000	C

TOLERANCE:

Tolerance Limit	
Low	High
0	0
100	100
1000	1000
1995	1995
2995	2995
5995	5995

CORNER TEST:

Corner 1	2000
Corner 2	2000
Corner 3	2000
Corner 4	2000

Indicator

1	2
4	3

CLASS III Maintenance TOLERANCE
Acceptance Tolerance = % of Maintenance Tolerance

0-500 Division Range = 1 Divisions Allowable Error
 501-2000 Division Range = 2 Divisions Allowable Error
 2001-4000 Division Range = 3 Divisions Allowable Error
 4001-5000 Division Range = 5 Divisions Allowable Error

Max Division Range = Capacity / Min Division
 Example: 100 / .02 = 5000 Max Divisions

Tolerance Limit = Test Load / Min Division
 Example: 25 / .02 = 1250 Division Range (Allowable Error = 2 divisions or + .04)

Pass Fail

Yes No

REPEATABILITY TEST

Test Weight	Reading 1	Zero	Reading 2	Zero	Reading 3	Zero
2000	2000	0	2000	0	2000	0

Comments / Observations:

SCALE IS WEIGHING WITHIN TOLERANCE

TEST STANDARDS USED: (Weight or Kit Serial Numbers)

Certification Performed By: WAYNE M.